

Instruction Sheet

Track Luminaire Installation

IMPORTANT SAFETY INSTRUCTIONS



- Read all installation instructions before installing. It is important to save these instructions.
- Observe and follow all label information and instructions regarding dry, damp and wet location listings, proper lamp type and wattage, warnings of installation near combustible materials and/or insulation.
- Turn off power at circuit breaker before attempting to install or perform maintenance on the fixtures.
- Wear rubber-soled shoes and work on a sturdy wooden ladder
- The product must be installed in a manner consistent with the intended use and in compliance with the national electrical codes and local codes.
- Ground fixture to avoid potential electrical shock.
- Do not install any fixture assembly closer than 6 inches from any curtain, or similar combustible material.
- **WARNING:** Lamp may be hot, allow lamp to cool before attempting to replace lamp (Do not use bar hand to replace lamp in fixture)
- Fluorescent and HID lamps contain a small amount of mercury as indicated by the **Hg** mark. Follow disposal laws. See www.lamprecycle.org. (LED fixtures do not contain mercury).
- **WARNING: RISK OF FIRE.** Minimum of 90°C supply conductors. Consult a qualified electrician before installation.

SINGLE CIRCUIT INSTALLATION INSTRUCTIONS

1. Turn power off.
2. Align the adapter and contacts parallel with track (Fig. 1).
3. Pull down the latch on the adapter and insert the adapter into the track.
Note: Twist the adapter and ground contact toward the polarity groove.
4. Support the fixture with one hand and twist the adapter 1/4 turn til the latch locks into the track.

REMOVAL INSTRUCTIONS

1. Turn power off.
2. Pull down the latch on the adapter and twist the adapter 1/4 turn.
3. Remove the fixture from the track.





TWO CIRCUIT INSTALLATION INSTRUCTIONS

1. Turn power off.
2. Adjust "Line" connector on track head to correct circuit being used with pliers (Fig. 3 or Fig. 4).
3. Align the adapter and contacts parallel with track (Fig. 1 or Fig. 2).
4. Pull down the latch on the adapter and insert the adapter into the track.
Note: Twist the adapter and ground contact toward the polarity groove.
5. Support the fixture with one hand and twist the adapter 1/4 turn til the latch locks into the track.

REMOVAL INSTRUCTIONS

1. Turn power off.
2. Pull down the latch on the adapter and twist the adapter 1/4 turn.
3. Remove the fixture from the track.





J-TYPE INSTALLATION INSTRUCTIONS

1. Turn power off.
2. Align the adapter and contacts parallel with track (Fig. 5).
3. Support the fixture with one hand. Pull down the latch on the adapter and rotate the adapter 90° counterclockwise. Release the latch and lock fixture into the track (Fig. 6).

REMOVAL INSTRUCTIONS

1. Turn power off.
2. Pull down the latch on the adapter and rotate the adapter 90° clockwise.
3. Remove the fixture from the track.





L-TYPE INSTALLATION INSTRUCTIONS

1. Turn power off.
2. Align the adapter and contacts parallel with track (Fig. 7)
3. Support the fixture with one hand. Pull down the latch on the adapter and rotate the adapter 90° counterclockwise. Release the latch and lock fixture into the track (Fig. 8).

REMOVAL INSTRUCTIONS

1. Turn power off.
2. Pull down the latch on the adapter and rotate the adapter 90° clockwise.
3. Remove the fixture from the track.





INTENSE LIGHTING 1-YEAR LIMITED WARRANTY

Intense Lighting warrants its properly installed products to be free of defects in material and workmanship in normal use, for a period of one year from the date of our shipment. Certain products may have a longer warranty period as noted on the product's specification sheet, Intense Lighting will repair or replace, at its option, any warranted product returned to it that it determines to be defective. This limited warranty does not include installation or removal, nor does it include lamps, transformers and ballasts, which are covered by their respective manufacturers. To receive credit for defective merchandise, product must undergo quality inspection prior to the processing of credit. If the product is found defective, you will be issued a credit. Product in good working condition will not receive a credit. Please inform your accounting department not to short pay or issue any debits to our company regarding a return. Testing and evaluation can take approximately 1-2 weeks based on quantity. At that time you will be notified if credit is granted for your warranty return.

THE ABOVE EXPRESS WARRANTY STATES THE FULL AND COMPLETE OBLIGATION OF INTENSE LIGHTING. ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO THE TERM OF THE EXPRESS WARRANTY. UNDER NO CIRCUMSTANCES WILL INTENSE LIGHTING ACCEPT LIABILITY FOR ANY CONSEQUENTIAL SPECIAL OR INDIRECT DAMAGES WHETHER ARISING OUT OF CONTRACT, TORT, OR STRICT LIABILITY.



INTENSE LIGHTING INTERIOR LED PRODUCTS 10-YEAR LIMITED WARRANTY

Intense Lighting warrants the LED electronics and components of its properly installed INTERIOR LED products listed below, to be free of defects in material and workmanship in normal use, for a period of 10 years from the date of our shipment or 50,000 hours of operation, whichever occurs first. Intense Lighting will repair or replace, at its option, any warranted product returned to it that it determines to be defective. Usage documentation may be requested to validate hours. This limited warranty does not include installation or removal, nor does it extend to the LED drivers which are warranted for five years. For the first year after the date of shipment, Intense Lighting will provide personnel to make field repairs for defective recessed fixtures only. Track fixtures must be sent back to factory for testing and evaluation. In addition to complete failure, defects include lumen depreciation to levels below 70% of initial lumen output within warranty period and/or color shift beyond that which is set forth in the Energy Star Program Requirements for SSL – Version 1.1 within warranty period.

Defects do not include improper installation or operation, alterations, power surges or overheating due to external conditions. To receive credit for defective merchandise, product must undergo quality inspection prior to the processing of credit. If the product is found defective, you will be issued a credit. Product in good working condition will not receive a credit. Please inform your accounting department not to short pay or issue any debits to our company regarding a return. Testing and evaluation can take approximately 1-2 weeks based on quantity. At that time you will be notified if credit is granted for your warranty return.

THE ABOVE EXPRESS WARRANTY STATES THE FULL AND COMPLETE OBLIGATION OF INTENSE LIGHTING. ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO THE TERM OF THE EXPRESS WARRANTY. UNDER NO CIRCUMSTANCES WILL INTENSE LIGHTING ACCEPT LIABILITY FOR ANY CONSEQUENTIAL SPECIAL OR INDIRECT DAMAGES WHETHER ARISING OUT OF CONTRACT, TORT, OR STRICT LIABILITY.

INSTRUCTIONS L/M-12192013 P-21

Intense Lighting | 2861. E La Palma Ave. | Anaheim, CA 92806 | **Phone:** 1.800.961.5321 | **Fax:** 1.800.961.5322 | www.intenselighting.com

Note: Instructions and dimensions subject to change without notice.

